



Multi-turn actuators

SAEx 07.2 – SAEx 16.2

SAREx 07.2 – SAREx 16.2

with actuator controls

AUMA MATIC BASIC AMBExC01.1



Read operation instructions first.

- Observe safety instructions.
- These operation instructions are part of the product.
- Preserve operation instructions during product life.
- Pass on instructions to any subsequent user or owner of the product.

Purpose of the document:

This document contains information for installation, commissioning, operation and maintenance staff. It is intended to support device installation and commissioning.

Reference documents:

Reference documents can be downloaded from the Internet (www.auma.com) or ordered directly from AUMA (refer to <Addresses>).

Table of contents	Page
1. Safety instructions.....	5
1.1. Basic information on safety	5
1.2. Range of application	5
1.3. Warnings and notes	6
1.4. References and symbols	7
2. Identification.....	8
2.1. Name plate	8
2.2. Short description	9
3. Transport, storage and packaging.....	10
3.1. Transport	10
3.2. Storage	10
3.3. Packaging	10
4. Assembly.....	11
4.1. Mounting position	11
4.2. Handwheel fitting	11
4.3. Multi-turn actuator: mount to valve/gearbox	11
4.3.1 Output drive types B, B1 – B4 and E	11
4.3.1.1 Multi-turn actuator (with output drive types B1 – B4 or E): mount to valve/gearbox	12
4.3.2 Output drive type A	12
4.3.2.1 Stem nut: finish machining	13
4.3.2.2 Multi-turn actuator (with output drive type A): mount to valve	14
4.4. Accessories for assembly	15
4.4.1 Stem protection tube for rising valve stem	15
4.5. Mounting positions of local controls	15
4.5.1 Mounting positions: modify	16
5. Electrical connection.....	17
5.1. Basic information	17
5.2. Connecting via plug/socket connector with screw-type terminals (KP, KPH)	18
5.2.1 Terminal compartment: open	18
5.2.2 Cable connection	19
5.2.3 Terminal compartment: close	20
5.3. Connecting via plug/socket connector with terminal blocks (KES)	21
5.3.1 Terminal compartment: open	21

5.3.2	Cable connection	22
5.3.3	Terminal compartment: close	23
5.4.	Accessories for electrical connection	23
5.4.1	Parking frame	23
5.4.2	Protection cover	24
5.4.3	Earth connection, external	24
6.	Operation.....	25
6.1.	Manual operation	25
6.1.1	Manual operation: engage	25
6.1.2	Manual operation: disengage	25
6.2.	Motor operation	25
6.2.1	Local operation	25
6.2.2	Actuator operation from remote	26
7.	Indications.....	27
7.1.	Indication lights	27
7.2.	Mechanical position indicator/running indication	27
8.	Signals.....	28
8.1.	Feedback signals (binary)	28
8.2.	Feedback signals (analogue)	28
9.	Commissioning (basic settings).....	29
9.1.	Switch compartment: open	29
9.2.	Torque switching: set	30
9.3.	Limit switching: set	30
9.3.1	End position CLOSED (black section): set	31
9.3.2	End position OPEN (white section): set	31
9.4.	Intermediate positions: set	32
9.4.1	Running direction CLOSE (black section): set	32
9.4.2	Running direction OPEN (white section): set	32
9.5.	Test run	33
9.5.1	Direction of rotation: check	33
9.5.2	Limit switching: check	34
9.6.	Potentiometer setting	34
9.7.	Electronic position transmitter RWG: set	35
9.8.	Mechanical position indicator: set	36
9.9.	Switch compartment: close	37
10.	Commissioning – controls settings.....	38
10.1.	Local controls: remove	38
10.2.	Type of seating: set	38
10.3.	Push-to-run operation or self-retaining: set	39
10.3.1	Push-to-run operation or self-retaining for operation commands via push buttons	39
10.3.2	Push-to-run operation or self-retaining for operation commands from Remote	39
10.4.	Local controls: mount	40
10.5.	Controls: open	41
10.6.	Feedback signals setting via output contacts	41
10.7.	Controls: close	42
11.	Corrective action.....	44
11.1.	Faults during commissioning	44
11.2.	Fuses	44

11.2.1	Fuses within the actuator controls	44
11.2.2	Motor protection (thermal monitoring)	46
12.	Servicing and maintenance.....	47
12.1.	Preventive measures for servicing and safe operation	47
12.2.	Disconnection from the mains	47
12.3.	Maintenance	48
12.4.	Disposal and recycling	49
13.	Technical data.....	50
13.1.	Features and functions of actuator	50
13.2.	Features and functions of actuator controls	52
13.3.	Service conditions	53
13.4.	Further information	54
14.	Spare parts.....	55
14.1.	Multi-turn actuators SAEx 07.2 – SAEx 16.2/SAREx 07.2 – SAREx 16.2 with plug/socket connector and screw-type terminals (KP, KPH)	55
14.2.	Actuator controls AUMA MATIC BASIC AMBExC 01.1 with plug/socket connector with screw-type connection (KP, KPH)	57
14.3.	Actuator controls AUMA MATIC BASIC AMBExC 01.1 with plug/socket connector and terminal blocks (KES)	59
15.	Certificates.....	61
15.1.	Declaration of Incorporation and EC Declaration of Conformity	61
15.2.	ATEX certificate	62
16.	Index.....	64
	Addresses.....	66

1. Safety instructions

1.1 Basic information on safety

Standards/directives	<p>AUMA products are designed and manufactured in compliance with recognised standards and directives. This is certified in a Declaration of Incorporation and an EC Declaration of Conformity.</p> <p>The end user or the contractor must ensure that all legal requirements, directives, guidelines, national regulations and recommendations with respect to assembly, electrical connection, commissioning and operation are met at the place of installation.</p> <p>They include among others standards and directives such as IEC/EN 60079 "Electrical apparatus for explosive atmospheres" –</p> <ul style="list-style-type: none"> • Part 14: Electrical installations in hazardous areas (other than mines). • Part 17: Inspection and maintenance of electrical installations in hazardous areas (other than mines).
Safety instructions/warnings	<p>All personnel working with this device must be familiar with the safety and warning instructions in this manual and observe the instructions given. Safety instructions and warning signs on the device must be observed to avoid personal injury or property damage.</p>
Qualification of staff	<p>Assembly, electrical connection, commissioning, operation, and maintenance must be carried out exclusively by suitably qualified personnel having been authorised by the end user or contractor of the plant only.</p> <p>Prior to working on this product, the staff must have thoroughly read and understood these instructions and, furthermore, know and observe officially recognised rules regarding occupational health and safety.</p> <p>Work performed in potentially explosive atmospheres is subject to special regulations which have to be observed. The end user or contractor of the plant are responsible for respect and control of these regulations, standards, and laws.</p>
Commissioning	<p>Prior to commissioning, it is important to check that all settings meet the requirements of the application. Incorrect settings might present a danger to the application, e.g. cause damage to the valve or the installation. The manufacturer will not be held liable for any consequential damage. Such risk lies entirely with the user.</p>
Operation	<p>Prerequisites for safe and smooth operation:</p> <ul style="list-style-type: none"> • Correct transport, proper storage, mounting and installation, as well as careful commissioning. • Only operate the device if it is in perfect condition while observing these instructions. • Immediately report any faults and damage and allow for corrective measures. • Observe recognised rules for occupational health and safety. • Observe the national regulations. • During operation, the housing warms up and surface temperatures > 60 °C may occur. To prevent possible burns, we recommend checking the surface temperature using an appropriate thermometer and wearing protective gloves, if required, prior to working on the device.
Protective measures	<p>The end user or the contractor are responsible for implementing required protective measures on site, such as enclosures, barriers, or personal protective equipment for the staff.</p>
Maintenance	<p>To ensure safe device operation, the maintenance instructions included in this manual must be observed.</p> <p>Any device modification requires prior consent of the manufacturer.</p>

1.2 Range of application

AUMA multi-turn actuators are designed for the operation of industrial valves, e.g. globe valves, gate valves, butterfly valves, and ball valves.

The devices described below are approved for use in the potentially explosive atmospheres of zones 1, 2, 21, and 22.

If temperatures >40 °C are to be expected at the valve mounting flange or the valve stem (e.g. due to hot media), please consult AUMA. Temperatures > 40 °C are not considered with regards to the non-electrical explosion protection.

Other applications require explicit (written) confirmation by the manufacturer.

The following applications are not permitted, e.g.:

- Industrial trucks according to EN ISO 3691
- Lifting appliances according to EN 14502
- Passenger lifts according to DIN 15306 and 15309
- Service lifts according to EN 81-1/A1
- Escalators
- Continuous duty
- Buried service
- Permanent submersion (observe enclosure protection)
- Potentially explosive areas of zones 0 and 20
- Potentially explosive areas of group I (mining)
- Radiation exposed areas in nuclear power plants

No liability can be assumed for inappropriate or unintended use.

Observance of these operation instructions is considered as part of the device's designated use.

Information These operation instructions are only valid for the "clockwise closing" standard version, i.e. driven shaft turns clockwise to close the valve.

1.3 Warnings and notes

The following warnings draw special attention to safety-relevant procedures in these operation instructions, each marked by the appropriate signal word (DANGER, WARNING, CAUTION, NOTICE).



Indicates an imminently hazardous situation with a high level of risk. Failure to observe this warning could result in death or serious injury.



Indicates a potentially hazardous situation with a medium level of risk. Failure to observe this warning could result in death or serious injury.



Indicates a potentially hazardous situation with a low level of risk. Failure to observe this warning may result in minor or moderate injury. May also be used with property damage.



Potentially hazardous situation. Failure to observe this warning may result in property damage. Is not used for personal injury.

Arrangement and typographic structure of the warnings




Type of hazard and respective source!

Potential consequence(s) in case of non-observance (option)

→ Measures to avoid the danger

→ Further measure(s)

Safety alert symbol  warns of a potential personal injury hazard.

The signal word (here: DANGER) indicates the level of hazard.

1.4


References and symbols

The following references and symbols are used in these instructions:

Information The term **Information** preceding the text indicates important notes and information.

 Symbol for CLOSED (valve closed)

 Symbol for OPEN (valve open)

 Important information before the next step. This symbol indicates what is required for the next step or what has to be prepared or observed.

< > **Reference to other sections**

Terms in brackets shown above refer to other sections of the document which provide further information on this topic. These terms are either listed in the index, a heading or in the table of contents and may quickly be found.

2. Identification

2.1 Name plate


Each device component (actuator, controls, motor) is equipped with a name plate.

Figure 1: Arrangement of name plates




- [1] Actuator name plate
- [2] Controls name plate
- [3] Motor name plate
- [4] Additional plate, e.g. KKS plate (Power Plant Classification System)
- [5] Explosion protection approval plate

Data for identification Figure 2: Actuator name plate



- [1] Type and size of actuator
- [2] Commission number

Figure 3: Controls name plate



- [1] Type and size of the controls
- [2] Commission number
- [3] Wiring diagram
- [4] Control

Figure 4: Explosion protection approval plate



- [1] Ex symbol, CE mark, ID no.
- [2] EC type examination certificate
- [3] Explosion protection classification - electrical explosion protection
- [4] Explosion protection classification - dust protection
- [5] Explosion protection classification - non-electrical explosion protection

Type and size

These instructions apply to the following devices:

Multi-turn actuators for open-close duty: SAEx 07.2, 07.6, 10.2, 14.2, 14.6, 16.2

Multi-turn actuators for modulating duty: SAREx 07.2, 07.6, 10.2, 14.2, 14.6, 16.2

AMBExC 01.1/02.1 = actuator controls AUMA MATIC BASIC

Commission number

An order-specific commission number is assigned to each device. This commission number can be used to directly download the wiring diagram, inspection records and further information regarding the device from the Internet: <http://www.auma.com>.

Control

24 V DC = control voltage for digital inputs = 24 V DC.

115 V AC = control voltage for digital inputs = 115 V AC.

230 V AC = control voltage for digital inputs = 230 V AC.

2.2 Short description

Multi-turn actuator

Definition in compliance with EN ISO 5210:

A multi-turn actuator is an actuator which transmits to the valve a torque for at least one full revolution. It is capable of withstanding thrust.

AUMA multi-turn actuators are driven by an electric motor and are capable of withstanding thrust in combination with output drive type A. For manual operation, a handwheel is provided. Switching off in end positions may be either by limit or torque seating. Controls are required to operate or process the actuator signals.

Actuator controls

The AUMA MATIC actuator controls are used to operate AUMA actuators and are supplied ready for use. The controls can be mounted directly to the actuator but also separately on a wall bracket. The electro-mechanical version of the AUMA MATIC controls includes switchgear for control in OPEN - CLOSE duty and a logic for various indications via contacts

Local controls

Operation (via push buttons), setting and indication can be performed directly at the controls (contents of these instructions).

3. Transport, storage and packaging

3.1 Transport

For transport to place of installation, use sturdy packaging.



Hovering load!

Risk of death or serious injury.

- Do NOT stand below hovering load.
- Attach ropes or hooks for the purpose of lifting by hoist only to housing and NOT to handwheel.
- Actuators mounted on valves: Attach ropes or hooks for the purpose of lifting by hoist to valve and NOT to actuator.
- Actuators mounted to gearboxes: Attach ropes or hooks for the purpose of lifting by hoist only to the gearbox using eyebolts and NOT to the actuator.
- Actuators mounted to controls: Attach ropes or hooks for the purpose of lifting by hoist only to the actuator and NOT to the controls.

3.2 Storage

NOTICE

Danger of corrosion due to inappropriate storage!

- Store in a well-ventilated, dry room.
- Protect against floor dampness by storage on a shelf or on a wooden pallet.
- Cover to protect against dust and dirt.
- Apply suitable corrosion protection agent to uncoated surfaces.

Long-term storage

If the device must be stored for a long period (more than 6 months) the following points must be observed in addition:

1. Prior to storage:
Protect uncoated surfaces, in particular the output drive parts and mounting surface, with long-term corrosion protection agent.
2. At an interval of approx. 6 months:
Check for corrosion. If first signs of corrosion show, apply new corrosion protection.

3.3 Packaging

Our products are protected by special packaging for transport when leaving the factory. The packaging consists of environmentally friendly materials which can easily be separated and recycled. We use the following packaging materials: wood, cardboard, paper, and PE foil. For the disposal of the packaging material, we recommend recycling and collection centres.

4. Assembly


4.1 Mounting position

AUMA actuators and actuator controls can be operated without restriction in any mounting position.

4.2 Handwheel fitting

Information For transport purposes, handwheels from a diameter of 400 mm are supplied separately.

Figure 5: Handwheel



- [1] Spacer
- [2] Input shaft
- [3] Handwheel
- [4] Circlip

1. If required, fit spacer [1] onto input shaft [2].
2. Slip handwheel [3] onto input shaft.
3. Secure handwheel [3] using the circlip [4] supplied.

4.3 Multi-turn actuator: mount to valve/gearbox

NOTICE

Danger of corrosion due to damage to paint finish and condensation!

- Touch up damage to paint finish after work on the device.
- After mounting, connect the device immediately to electrical mains to ensure that heater minimises condensation.


4.3.1 Output drive types B, B1 – B4 and E

- Application**
- For rotating, non-rising valve stem
 - Not capable of withstanding thrust

Design Output drive bore with keyway:

- Types B1 – B4 with bore according to ISO 5210
- Types B and E with bore according to DIN 3210
- Later change from B1 to B3, B4, or E is possible.

Figure 6: Output drive



- [1] Output drive types B, B1 – B4, E and C
[2] Output drive sleeve/output drive plug sleeve with bore and keyway
[3] Circlip

Information Spigot at flanges should be loose fit.

4.3.1.1 Multi-turn actuator (with output drive types B1 – B4 or E): mount to valve/gearbox

1. Check if mounting flanges fit together.
2. Check whether bore and keyway match the input shaft.
3. Apply a small quantity of grease to the input shaft.
4. Place multi-turn actuator.
Information: Ensure that the spigot fits uniformly in the recess and that the mounting faces are in complete contact.
5. Fasten multi-turn actuator with screws according to table.
Information: We recommend applying liquid thread sealing material to the screws to avoid contact corrosion.
6. Fasten screws crosswise to a torque according to table.

Table 1: Tightening torques for screws

Screws	Tightening torque T_A [Nm]
Threads	Strength class 8.8
M8	25
M10	51
M12	87
M16	214
M20	431

4.3.2 Output drive type A


- Application**
- Output drive for rising, non-rotating valve stem
 - Capable of withstanding thrust

Information To adapt the actuators to output drive types A available on site with flanges F10 and F14 (year of manufacture: 2009 and earlier), an adapter is required. The adapter can be ordered from AUMA.

4.3.2.1 Stem nut: finish machining

- ✓ This working step is only required if stem nut is supplied unbored or with pilot bore.

Figure 7: Design of output drive type A




- [1] Stem nut
- [2] Bearing
- [2.1] Bearing race
- [2.2] Bearing rim
- [3] Spigot ring

1. Remove spigot ring [3] from output drive.
2. Remove stem nut [1] together with bearings [2].
3. Remove bearing races [2.1] and bearing rims [2.2] from stem nut [1].
4. Drill and bore stem nut [1] and cut thread.
Information: When fixing in the chuck, make sure stem nut runs true!
5. Clean the machined stem nut [1].
6. Apply sufficient Lithium soap EP multi-purpose grease to bearing rims [2.2] and bearing races [2.1], ensuring that all hollow spaces are filled with grease.
7. Place greased bearing rims [2.2] and bearing races [2.1] onto stem nut [1].
8. Re-insert stem nut [1] with bearings [2] into output drive.
Information: Ensure that dogs or splines are placed correctly in the keyway of the hollow shaft.
9. Screw in spigot ring [3] until it is firm against the shoulder.

4.3.2.2 Multi-turn actuator (with output drive type A): mount to valve

Figure 8: Assembly with output drive type A



- [1] Valve stem
- [2] Output drive type A
- [3] Screws to actuator
- [4] Valve flange
- [5] Screws to output drive

1. If the output drive type A is already mounted to the multi-turn actuator: Loosen screws [3] and remove output drive type A [2].
2. Check if the flange of output drive type A matches the valve flange [4].
3. Apply a small quantity of grease to the valve stem [1].
4. Place output drive type A on valve stem and turn until it is flush on the valve flange.
5. Turn output drive type A until alignment of the fixing holes.
6. Screw in fastening screws [5], however do not completely tighten.
7. Fit multi-turn actuator on the valve stem so that the stem nut dogs engage into the output drive sleeve.
- ➡ The flanges are flush with each other if properly engaged.
8. Adjust multi-turn actuator until alignment of the fixing holes.
9. Fasten multi-turn actuator with screws [3].
10. Fasten screws [3] crosswise with a torque according to table.

Table 2: Tightening torques for screws

Screws	Tightening torque T_A [Nm]
Threads	Strength class 8.8
M6	11
M8	25
M10	51
M12	87
M16	214
M20	431


11. Turn multi-turn actuator with handwheel in direction OPEN until valve flange and output drive A are firmly placed together.
12. Tighten fastening screws [5] between valve and output drive type A crosswise applying a torque according to table.

4.4 Accessories for assembly

4.4.1 Stem protection tube for rising valve stem

— Option —

Figure 9: Assembly of the stem protection tube



- [1] Cap for stem protection tube
- [2] Stem protection tube
- [3] Sealing ring

1. Seal thread with hemp, Teflon tape, or thread sealing material.
2. Screw stem protection tube [2] into thread and tighten it firmly.
3. Push down the sealing ring [3] onto the housing.
4. Check whether cap for stem protection tube [1] is available and in perfect condition.

4.5 Mounting positions of local controls

The mounting position of the local controls is selected according to the order. If, after mounting the actuator to the valve or the gearbox on site, the local controls are in an unfavourable position, the mounting position can be changed at a later date. Four mounting positions are possible.

Figure 10: Mounting positions A and B



Figure 11: Mounting positions C and D



4.5.1 Mounting positions: modify



Flameproof enclosure, danger of explosion!

Risk of death or serious injury.

- Before opening, ensure that there is no explosive gas and no voltage.
- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

1. Loosen screws and remove the local controls.
2. Loosen 3 screws of the board, turn board to the new position and fasten the screws.
3. Check whether O-ring is in good condition, correctly insert O-ring.
4. Turn local controls into new position and re-place.

NOTICE

Cable damage due to twisting or pinching!

Risk of functional failures.

- Turn local controls by a maximum of 180°.
- Carefully assemble local controls to avoid pinching the cables.

5. Fasten screws evenly crosswise.

5. Electrical connection

5.1 Basic information



Danger due to incorrect electrical connection

Failure to observe this warning can result in death, serious injury, or property damage.

- The electrical connection must be carried out exclusively by suitably qualified personnel.
- Prior to connection, observe basic information contained in this chapter.
- After connection but prior to applying the voltage, observe the <Commissioning> and <Test run> chapters.

Wiring diagram/terminal plan

The pertaining wiring diagram/terminal plan (in German and English language) is attached to the device in a weather-proof bag, together with these operation instructions. It can also be obtained from AUMA (state commission no., refer to name plate) or downloaded directly from the Internet (www.auma.com).

Protection on site

For short-circuit protection and for disconnecting the actuator from the mains, fuses and disconnect switches have to be provided by the customer.

The current values for respective sizing is derived from the current consumption of the motor (refer to electrical data sheet) plus the current consumption of the controls.

Table 3: Current consumption controls

Mains voltage	Max. current consumption
100 to 120 V AC (±10 %)	575 mA
208 to 240 V AC (±10 %)	275 mA
380 to 500 V AC (±10 %)	160 mA
24 V DC (+20 %/–15 %) and AC motor	500 mA

Table 4: Maximum permissible protection

Switchgear	Rated power	max. protection
Reversing contactor	up to 1.5 kW	16 A (gL/gG)
Reversing contactor	up to 7.5 kW	32 A (gL/gG)
Reversing contactor	up to 11 kW	63 A (gL/gG)

If controls are mounted separately from actuator (controls on wall bracket): Consider length and cross section of connecting cable when defining the protection required.


Power supply for the controls (electronics)

If the controls (electronics) are supplied externally with 24 V DC, the power supply is smoothed via an internal 1,000 µF capacitor). When selecting a power supply, care must be taken to consider the capacitor inrush current upon powering the unit up.

Type of current, mains voltage and mains frequency

Type of current, mains voltage and mains frequency must match the data on the motor name plate.

Figure 12: Motor name plate (example)




- [1] Type of current
 [2] Mains voltage
 [3] Mains frequency (for 3-ph and 1-ph AC motors)

Connecting cables

- For device insulation, appropriate (voltage-proof) cables must be used. Specify cables for the highest occurring rated voltage.
- Use connecting cables with a minimum temperature range of +80 °C.
- For connecting cables exposed to UV radiation (outdoor installation), use UV resistant cables.

5.2 Connecting via plug/socket connector with screw-type terminals (KP, KPH)**5.2.1 Terminal compartment: open**

Figure 13: Plug/socket connector KPH, KP



- [1] Cover
 [2] Screws for cover
 [3] O-ring
 [4] Terminal compartment
 [5] Terminal board

**Hazardous voltage!**

Risk of electric shock.

→ Disconnect device from the mains before opening.

1. Loosen screws [2] and remove cover [1].
 ➔ Terminal compartment [4] is designed for explosion protection Ex e (increased safety). The flameproof compartment (type of protection Ex d) remains hereby closed.

2. Insert cable glands with Ex e approval and of size suitable for connection cables.
- The enclosure protection IP... stated on the name plate is only ensured if suitable cable glands are used. Example: Name plate shows enclosure protection IP 68.



3. Seal cable entries which are not used with approved plugs suitable for the required protection type.
4. Insert the wires into the cable glands.

5.2.2 Cable connection

Table 5: Terminal cross sections and tightening torques

Type	Terminal cross sections	Tightening torques
Power terminals (U1, V1, W1) PE connection	(1.5) ¹⁾ 2.5 – 6 mm ² (flexible or solid)	2 Nm
Control contacts (1 to 50)	0.75 – 1.5 mm ² (flexible or solid)	1 Nm

1) with small clamp washers

1. Remove cable sheathing in a length of 120 – 140 mm.
2. Strip wires.
 - Controls max. 8 mm, motor 12 mm
3. For flexible cables: Use end sleeves according to DIN 46228.
4. Connect cables according to order-related wiring diagram.

Information: Two wires for each connection permitted.

→ When using motor cables with a cross section of 1.5 mm²: Use small clamp washers for connection to terminals U1, V1, W1 and PE (the small clamp washers are provided in the electrical connection cover).




In case of a fault: Hazardous voltage while protective earth conductor is NOT connected!

Risk of electric shock.

- Connect all protective earth conductors.
- Connect PE connection to external protective earth conductor of connecting cables.
- Start running the device only after having connected the protective earth conductor.

5. Tighten protective earth firmly to PE connection

Figure 15: PE connection



- [1] PE connection, control cable
- [2] PE connection, motor cable

NOTICE

Danger of corrosion: Damage due to condensation!


- After mounting, commission the device immediately to ensure that heater minimises condensation.

Information

Some actuators are equipped with an additional motor heater. The motor heater minimises condensation within the motor and improves the start-up behaviour for extremely low temperatures.

5.2.3 Terminal compartment: close

Figure 16: Plug/socket connector KPH, KP




- [1] Cover
- [2] Screws for cover
- [3] O-ring
- [4] Terminal compartment
- [5] Terminal board

1. Clean sealing faces of cover [1] and housing.
2. Check whether O-ring [3] is in good condition, replace if damaged.
3. Apply a thin film of non-acidic grease (e.g. petroleum jelly) to the O-ring and insert it correctly.
4. Fit cover [1] and fasten screws [2] evenly crosswise.
5. Fasten cable glands with the specified torque to ensure the required enclosure protection.

5.3 Connecting via plug/socket connector with terminal blocks (KES)

5.3.1 Terminal compartment: open

Figure 17: Plug/socket connector: left KES, right KES flameproof



- [1] Cover
- [2] Screws for cover
- [3] O-ring
- [4] Terminal compartment: Type of protection Ex e
- [5] Terminal compartment: Type of protection Ex d
- [6] Frame

DANGER

Hazardous voltage!

Risk of electric shock.

→ Disconnect device from the mains before opening.

1. Loosen screws [2] and remove cover [1].
- ➔ Terminal compartments [4] and [5] are designed either in type of protection Ex e (increased safety) or in type of protection Ex d (flameproof enclosure). Hereby, the flameproof interior compartment of the actuator (Ex d) remains closed.
2. Insert cable glands with Ex e approval and suitable for connection cables.
- ➔ The enclosure protection IP... stated on the name plate is only ensured if suitable cable glands are used. Example: Name plate shows enclosure protection IP 68.



3. Seal cable entries unused cable entries with approved plugs suitable for the required protection type.
4. Remove cable sheathing and insert the wires into the cable glands.
5. Fasten cable glands with the specified torque to ensure required enclosure protection.

5.3.2 Cable connection

Table 6: Terminal cross sections and tightening torques

Type	Terminal cross sections	Tightening torques
Power terminals (U, V, W)	max. 10 mm ² (flexible or solid)	1.5 – 1.8 Nm
PE connection	max. 10 mm ² (flexible or solid)	3.0 – 4.0 Nm
Control contacts (1 to 50)	max. 2.5 mm ² (flexible or solid)	0.6 – 0.8 Nm

1. Strip wires.
2. For flexible cables: Use end sleeves according to DIN 46228.
3. Connect cables according to order-related wiring diagram.



WARNING


In case of a fault: Hazardous voltage while protective earth conductor is NOT connected!

Risk of electric shock.

- Connect all protective earth conductors.
- Connect PE connection to external protective earth conductor of connecting cables.
- Start running the device only after having connected the protective earth conductor.

4. Tighten protective earth firmly to PE connection

Figure 19: PE connection



- [1] Terminal blocks
 [2] Terminal housing
 [3] PE connection, symbol:

NOTICE

Danger of corrosion: Damage due to condensation!


- After mounting, commission the device immediately to ensure that heater minimises condensation.

Information

Some actuators are equipped with an additional motor heater. The motor heater minimises condensation within the motor and improves the start-up behaviour for extremely low temperatures.

5.3.3 Terminal compartment: close

Figure 20: Plug/socket connector: left KES, right KES flameproof



- [1] Cover
- [2] Screws for cover
- [3] O-ring
- [4] Terminal compartment: Type of protection Ex e
- [5] Terminal compartment: Type of protection Ex d
- [6] Frame

1. Clean sealing faces of cover [1] and housing.
2. Plug/socket connector designed as KES flameproof: Preserve joint surfaces with an acid-free corrosion protection agent.
3. Check whether O-ring [3] is in good condition, replace if damaged.
4. Apply a thin film of non-acidic grease (e.g. petroleum jelly) to the O-ring and insert it correctly.



WARNING

Flameproof enclosure, danger of explosion!

Risk of death or serious injury.

- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

5. Fit cover [1] and fasten screws [2] evenly crosswise.

5.4 Accessories for electrical connection

— Option —

5.4.1 Parking frame

Application

Parking frame for safe storage of a disconnected plug.

For protection against touching the bare contacts and against environmental influences.

Figure 21: Parking frame and plug/socket connector with screw-type terminals (KP/KPH)





Figure 22: Parking frame and plug/socket connector with terminal blocks (KES)



5.4.2 Protection cover

Protection cover for plug compartment when plug is removed.

The open terminal compartment can be closed using a protective cover (not illustrated).

5.4.3 Earth connection, external

The housing is equipped with an external earth connection (U-bracket) to connect the device to the equipotential earth bonding.

Figure 23: Earth connection



6. Operation

6.1 Manual operation

For purposes of setting and commissioning, in case of motor failure or power failure, the actuator may be operated manually. Manual operation is engaged by an internal change-over mechanism.


6.1.1 Manual operation: engage

NOTICE

Damage at the motor coupling due to faulty operation!

→ Engage manual operation only during motor standstill.


1. Press push button.



2. Turn handwheel in desired direction.

→ To close the valve, turn handwheel clockwise:

↪ Drive shaft (valve) turns clockwise in direction CLOSE.



6.1.2 Manual operation: disengage

Manual operation is automatically disengaged when motor is started again. The handwheel does not rotate during motor operation.


6.2 Motor operation

- ✓ Perform all commissioning settings and the test run prior to motor operation.

6.2.1 Local operation

The local operation of the actuator is performed using the push buttons of the local controls.

Figure 26: Local controls



- [1] Push button for operation command in direction OPEN
- [2] Push button Stop
- [3] Push button for operation command in direction CLOSE
- [4] Selector switch



Hot surfaces, e.g. possibly caused by high ambient temperatures or strong direct sunlight!

Danger of burns

→ Check surface temperature and wear protective gloves, if required.

→ Set selector switch [4] to position **Local control** (LOCAL).




- ➔ The actuator can now be operated using the push buttons [1 – 3]:
 - Run actuator in direction OPEN: Press push button [1]
 - Stop actuator: Press push button [2] **Stop**.
 - Run actuator in direction CLOSE: Press push button [3]

Information The OPEN - CLOSE operation commands can be given either in push-to-run operation mode or in self-retaining mode. In self-retaining mode, the actuator runs to the defined end position after pressing the button, unless another command has been received beforehand.

6.2.2 Actuator operation from remote

→ Set selector switch to **Remote control** (REMOTE).




- ➔ Now, it is possible to operate the actuator via remote control, via operation commands (OPEN, STOP, CLOSE).

7. Indications

7.1 Indication lights

Figure 29: Local controls with indication lights



- [1] illuminated (green): End position OPEN reached
- [2] illuminated (red): Fault signal (option)
- [3] illuminated (yellow): End position CLOSED reached

Fault signal (option) The fault signal (red indication light) indicates the following events:

- Torque fault: The set torque was exceeded before reaching an end position.
- Thermal fault: Motor protection has tripped, i.e. the motor is overheated.

7.2 Mechanical position indicator/running indication

— Option —

Mechanical position indicator:

- Continuously indicates the valve position
(For complete travel from OPEN to CLOSED or vice versa, the indicator disc [2] rotates by approximately 180° to 230°.)
- Indicates whether the actuator is running (running indication)
- Indicates that the end positions are reached (via indicator mark [3])

Figure 30: Mechanical position indicator



- [1] Cover
- [2] Indicator disc
- [3] Mark
- [4] Symbol for position OPEN
- [5] Symbol for position CLOSED

8. Signals

8.1 Feedback signals (binary)

Information The switches can be provided as single switches (1NC and 1 NO), as tandem switches (2 NC and 2 NO) or as triple switches (3 NC and 3 NO). The precise version is indicated in the terminal plan or on the order-related technical data sheet.

Feedback signal	Type and designation in wiring diagram
End position OPEN/CLOSED reached	Signalling via limit switches (NO), non potential-free Value of the output signal depends on control voltage (refer to wiring diagram)
	LSC Limit switch, closing, clockwise rotation
	LSO Limit switch, opening, counterclockwise rotation
	Option: Tandem switch with additional potential-free contacts LSC1 and LSO1
Intermediate position reached (option)	Potential-free signal via switches (NC/NO) Condition: DUO limit switching in the actuator
	LSA DUO limit switch, clockwise rotation
	LSB DUO limit switch, counterclockwise rotation
Torque o.k./ Torque fault	Potential-free signal via contacts, terminals XK 15 and XK 16 Condition: Relay board A5 within the controls Output contact XK 15 closed = no torque fault Output contact XK 16 = torque fault, i.e. the set torque was exceeded before reaching an end position.
Torque OPEN/CLOSED reached (option)	Potential-free signal via switches (NC/NO) Condition: Torque switch in tandem arrangement with TSC/TSO
	TSC1 Torque switch, closing, clockwise rotation
	TSO 1 Torque switch, opening, counterclockwise rotation
Motor protection tripped (option)	Potential-free signal via contacts, terminal XK 13 Condition: Relay board A5 within the controls Thermoswitch tripped (NO contact) = Output contact closed
	F1, Th Thermoswitches
	F7 Thermal overload relay
Selector switch position (option)	Potential-free signal via switches (2 x NC) Condition: Selector switch with 2 levels indicates selector switch position LOCAL/REMOTE
Running indication (option)	Potential-free signal via switch (NC) Contact opens and closes (blinks) during an actuator operation
	S5, BL Blinker transmitter

8.2 Feedback signals (analogue)

Feedback signal	Type and designation in wiring diagram
Valve position (option)	Via potentiometer or electronic position transmitter RWG, depending on the version
	R2 Potentiometer
	R2/2 Potentiometer in tandem arrangement (option)
	B1/B2, RWG 3- or 4-wire system (0/4– 20 mA)
	B3/B4, RWG 2-wire system (4 – 20 mA)

9. Commissioning (basic settings)

1. Set selector switch to position **0** (OFF).



Information: The selector switch is not a mains switch. When positioned to **0** (OFF), the actuator cannot be operated. The controls' power supply is maintained.

2. Switch on the power supply.

Information: Please consider the heat-up time for ambient temperatures below $-20\text{ }^{\circ}\text{C}$.

3. Perform basic settings.

9.1 Switch compartment: open

The switch compartment must be opened to perform the following settings (options).




Flameproof enclosure, danger of explosion!

Risk of death or serious injury.

- Before opening, ensure that there is no explosive gas and no voltage.
- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

1. Loosen screws [2] and remove cover [1] from the switch compartment.

Figure 32:




2. If indicator disc [3] is available:

Remove indicator disc [3] using a spanner (as lever).

Information: To avoid damage to paint finish, use spanner in combination with soft object, e.g. fabric.

Figure 33:



9.2 Torque switching: set

Once the set torque is reached, the torque switches will be tripped (overload protection of the valve).


Information The torque switches may also trip during manual operation.

NOTICE

Valve damage due to excessive tripping torque limit setting!

- The tripping torque must suit the valve.
- Only change the setting with the consent of the valve manufacturer.

Figure 34: Torque switching heads



- [1] Torque switching head black in direction CLOSE
- [2] Torque switching head white in direction OPEN
- [3] Lock screws
- [4] Torque dials

1. Loosen both lock screws [3] at the indicator disc.
2. Turn torque dial [4] to set the required torque (1 da Nm = 10 Nm).
3. Fasten lock screws [3] again.

Information: Maximum tightening torque: 0.3 – 0.4 Nm

➡ The torque switch setting is complete.

Example: The figure above shows the following settings:

- 3.5 da Nm = 35 Nm for direction CLOSE
- 4.5 da Nm = 45 Nm for direction OPEN

9.3 Limit switching: set

The limit switching records the travel. When reaching the preset position, switches are operated.

Figure 35: Setting elements for limit switching



Black section:

- [1] Setting spindle: End position CLOSED
- [2] Pointer: End position CLOSED
- [3] Mark: End position CLOSED is set

White section:

- [4] Setting spindle: End position OPEN
- [5] Pointer: End position OPEN
- [6] Mark: End position OPEN is set

9.3.1 End position CLOSED (black section): set

1. Engage manual operation.
2. Turn handwheel clockwise until valve is closed.
3. Turn handwheel by approximately half a turn (overrun) in the opposite direction.
4. **Press down** and turn setting spindle [1] with screw driver in direction of the arrow and observe the pointer [2]: While a ratchet click is felt and heard, the pointer [2] moves 90° every time.
5. If the pointer [2] is 90° from mark [3]: Continue turning slowly.
6. If the pointer [2] moves to mark [3]: Stop turning and release setting spindle.
- ➔ The end position CLOSED setting is complete.
7. If you override the tripping point inadvertently (ratchet click is heard after the pointer has snapped): Continue turning the setting spindle in the same direction and repeat setting process.


9.3.2 End position OPEN (white section): set

1. Engage manual operation.
2. Turn handwheel counterclockwise until valve is open.
3. Turn handwheel by approximately half a turn (overrun) in the opposite direction.
4. **Press down** and turn setting spindle [4] with screw driver in direction of the arrow and observe the pointer [5]: While a ratchet click is felt and heard, the pointer [5] moves 90° every time.
5. If the pointer [5] is 90° from mark [6]: Continue turning slowly.
6. If the pointer [5] moves to mark [6]: Stop turning and release setting spindle.
- ➔ The end position OPEN setting is complete.
7. If you override the tripping point inadvertently (ratchet click is heard after the pointer has snapped): Continue turning the setting spindle in the same direction and repeat setting process.

9.4 Intermediate positions: set**— Option —**

Actuators equipped with DUO limit switching contain two intermediate position switches. One intermediate position may be set for each running direction.

Figure 36: Setting elements for limit switching

**Black section:**

- [1] Setting spindle: Running direction CLOSE
- [2] Pointer: Running direction CLOSE
- [3] Mark: Intermediate position CLOSED is set

White section:

- [4] Setting spindle: Running direction OPEN
- [5] Pointer: Running direction OPEN
- [6] Mark: Intermediate position OPEN is set

Information After 177 turns (control unit for 1 – 500 turns/stroke) or 1,769 turns (control unit for 1 – 5,000 turns/stroke), the intermediate switches release the contact.

9.4.1 Running direction CLOSE (black section): set

1. Move valve in direction CLOSE to desired intermediate position.
2. If you override the tripping point inadvertently: Turn valve in opposite direction and approach intermediate position again in direction CLOSE.
Information: Always approach the intermediate position in the same direction as in later electrical operation.
3. **Press down** and turn setting spindle [1] with screw driver in direction of the arrow and observe the pointer [2]: While a ratchet click is felt and heard, the pointer [2] moves 90° every time.
4. If the pointer [2] is 90° from mark [3]: Continue turning slowly.
5. If the pointer [2] moves to mark [3]: Stop turning and release setting spindle.
- ➡ The intermediate position setting in running direction CLOSE is complete.
6. If you override the tripping point inadvertently (ratchet click is heard after the pointer has snapped): Continue turning the setting spindle in the same direction and repeat setting process.

9.4.2 Running direction OPEN (white section): set

1. Move valve in direction OPEN to desired intermediate position.
2. If you override the tripping point inadvertently: Move valve in opposite direction and approach intermediate position again in direction OPEN (always approach the intermediate position in the same direction as in later electrical operation).

3. **Press down** and turn setting spindle [4] with screw driver in direction of the arrow and observe the pointer [5]: While a ratchet click is felt and heard, the pointer [5] moves 90° every time.
4. If the pointer [5] is 90° from mark [6]: Continue turning slowly.
5. If the pointer [5] moves to mark [6]: Stop turning and release setting spindle.
- ➔ The intermediate position setting in running direction OPEN is complete.
6. If you override the tripping point inadvertently (ratchet click is heard after the pointer has snapped): Continue turning the setting spindle in the same direction and repeat setting process.

9.5 Test run

Perform test run only once all settings previously described have been performed.

9.5.1 Direction of rotation: check

NOTICE

Valve damage due to incorrect direction of rotation!

- If the direction of rotation is wrong, switch off immediately (press STOP).
- Eliminate cause, i.e. correct phase sequence for cable set wall bracket.
- Repeat test run.

1. Move actuator manually to intermediate position or to sufficient distance from end position.
2. Set selector switch to position **Local control** (LOCAL).




3. Switch on actuator in running direction CLOSE and observe the direction of rotation:
with indicator disc: step 4
without indicator disc: step 5 (hollow shaft)
→ Switch off before reaching the end position.
4. With indicator disc:
→ Observe direction of rotation.
➔ The direction of rotation is correct, if **actuator runs in direction CLOSE** and **indicator disc turns counterclockwise**.




5. Without the indicator disc:
 - Unscrew threaded plug [1] and seal [2] or cap for stem protection tube [4] and observe direction of rotation at hollow shaft [3] or the stem [5].
 - ➔ The direction of rotation is correct, if **actuator runs in direction CLOSE** and hollow shaft or stem **turn clockwise**.

Figure 39: Hollow shaft/stem



9.5.2 Limit switching: check

1. Set selector switch to position **Local control** (LOCAL).



2. Operate actuator using push buttons OPEN - STOP - CLOSE.
 - ➔ The limit switching is set correctly if (default indication):
 - the yellow indication light is illuminated in end position CLOSED
 - the green indication light is illuminated in end position OPEN
 - the indication lights go out after travelling into the opposite direction.
 - ➔ The limit switching is set incorrectly if:
 - the actuator comes to a standstill before reaching the end position
 - the red indication light is illuminated (torque fault).
3. If the end position setting is incorrect: Reset limit switching.
4. If the end position setting is correct and no options (e.g. potentiometer, position transmitter) are available: Close switch compartment.

9.6 Potentiometer setting

— Option —

The potentiometer as travel sensor records the valve position.

Information This setting is only required if the potentiometer is directly wired to the customer connection XK (refer to wiring diagram).

Information
Due to the ratio of the reduction gearing the complete resistance range/stroke is not always passed. Therefore, external adjustment (setting potentiometer) must be provided.

Figure 41: View of control unit



[1] Potentiometer

1. Move valve to end position CLOSED.
2. Turn potentiometer [1] clockwise to the stop.
 - ➔ End position CLOSED corresponds to 0 %
 - ➔ End position OPEN corresponds to 100 %
3. Turn potentiometer [1] slightly in opposite direction.
4. Perform fine-tuning of the zero point at external setting potentiometer (for remote indication).

9.7

Electronic position transmitter RWG: set

— Option —

The electronic position transmitter RWG records the valve position. On the basis of the actual position value measured by the potentiometer (travel sensor), it generates a current signal between 0 – 20 mA or 4 – 20 mA.

Table 7: Technical data RWG 4020

Wiring		3- or 4-wire system
Terminal plan	KMS	TP__4/ _ _ _
Output current	I _A	0 – 20 mA, 4 – 20 mA
Power supply	U _V	24 V DC, ±15 % smoothed
Max. current consumption	I	24 mA at 20 mA output current
Max. load	R _B	600 Ω

Figure 42: View of control unit





- [1] Potentiometer (travel sensor)
- [2] Potentiometer min. (0/4 mA)
- [3] Potentiometer max. (20 mA)
- [4] Measuring point (+) 0/4 – 20 mA
- [5] Measuring point (–) 0/4 – 20 mA

1. Connect voltage to electronic position transmitter.
2. Move valve to end position CLOSED.
3. Connect ammeter for 0 – 20 mA to measuring points [4 and 5]. If no value can be measured:
 - 3.1 Check, whether external load is connected to customer connection XK (terminals 23/24) (observe max. load R_B), or
 - 3.2 Connect terminals 23/24 across customer connection XK (terminals 23/24).
4. Turn potentiometer [1] clockwise to the stop.
5. Turn potentiometer [1] slightly in opposite direction.
6. Turn potentiometer [2] clockwise until output current starts to increase.
7. Turn potentiometer [2] in opposite direction until the following value is reached:
 - for 0 – 20 mA approx. 0.1 mA
 - for 4 – 20 mA approx. 4.1 mA
- ➡ This ensures that the signal remains above the dead and live zero point.
8. Move valve to end position OPEN.
9. Set potentiometer [3] to end value 20 mA.
10. Approach end position CLOSED again and check minimum value (0.1 mA or 4.1 mA). If necessary, correct the setting.


Information If the maximum value cannot be reached, the selection of the reduction gearing must be checked. (The max. possible turns/stroke are indicated on the order-related technical data sheet for the actuator.)

9.8 Mechanical position indicator: set


— Option —

1. Place indicator disc on shaft.
2. Move valve to end position CLOSED.
3. Turn lower indicator disc until symbol  (CLOSED) is in alignment with the mark  on the cover.



4. Move actuator to end position OPEN.
5. Hold lower indicator disc in position and turn upper disc with symbol  (OPEN) until it is in alignment with the mark ▲ on the cover.



6. Move valve to end position CLOSED again.
7. Check settings:
If the symbol  (CLOSED) is no longer in alignment with mark ▲ on the cover:
7.1 Repeat setting procedure.
7.2 Check whether the appropriate reduction gearing has been selected, if required.

9.9 Switch compartment: close

NOTICE

Danger of corrosion due to damage to paint finish!

→ Touch up damage to paint finish after work on the device.

1. Clean sealing faces of housing and cover.
2. Preserve joint surfaces with an acid-free corrosion protection agent.
3. Check whether O-ring [3] is in good condition, replace if damaged.
4. Apply a thin film of non-acidic grease (e.g. petroleum jelly) to the O-ring and insert it correctly.



⚠ WARNING

Flameproof enclosure, danger of explosion!

Risk of death or serious injury.

- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

5. Place cover [1] on switch compartment.
6. Fasten screws [2] evenly crosswise.

10. Commissioning – controls settings

The controls are set in the factory according to the order. The settings only have to be changed if the device is used for applications other than those specified in the order.

The following settings are described in these operation instructions:

- Setting the type of seating (limit or torque seating)
- Setting push-to-run operation or self-retaining
- Feedback signals setting via output contacts (option)

10.1 Local controls: remove

**WARNING**

Flameproof enclosure, danger of explosion!

Risk of death or serious injury.


- Before opening, ensure that there is no explosive gas and no voltage.
- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

NOTICE

Electrostatic discharge ESD!

Risk of damage to electronic components.

- Earth both operators and devices.
- Loosen screws [2] and carefully remove local controls [1].



10.2 Type of seating: set

NOTICE

Valve damage due to incorrect setting!

- The type of seating must suit the valve.
- Only change the setting with the consent of the valve manufacturer.

The type of seating can be set via a toggle switch on the signal and control board.

Limit seating

The limit switching is set in such a way that the actuator switches off at the desired switching points. The torque switching acts as overload protection for the valve.


Torque seating

The torque switching is set to the desired tripping torque. After reaching the tripping torque, the actuator is turned off.

The limit switching is used for signalling and must be set to trip shortly **before** reaching the set tripping torque.

→ Set type of seating via toggle switch [S9].

Figure 47: Signal and control board



[S9] Toggle switch
in position $\text{I} \sim \text{M}$ = limit seating
in position $\text{M} \sim \text{I}$ = torque seating

10.3 Push-to-run operation or self-retaining: set

The operation behaviour for operation commands (OPEN, STOP, CLOSE) can be set separately via the push buttons on the local controls or for operation commands from Remote.

Push-to-run operation

Actuator only runs in directions OPEN or CLOSE while an operation command is being received. The actuator stops if the operation command is cancelled.


Self-retaining

After an operation command, the actuator continues to run in directions OPEN or CLOSE, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if an end position or intermediate position has been reached.

10.3.1 Push-to-run operation or self-retaining for operation commands via push buttons

Push-to-run operation or self-retaining for operation commands is set in the factory and usually remains unchanged. Subsequent modification is however possible but by interrupting or soldering a link on the signal and control board.

Figure 48: Signal and control board



[B3] Soldering link closed = self-retaining LOCAL
[B3] Soldering link interrupted = push-to-run operation LOCAL


10.3.2 Push-to-run operation or self-retaining for operation commands from Remote

The settings for push-to-run operation or self-retaining from Remote is made via a jumper on the wiring board.

1. Loosen all 3 screws [2] on the signal and control board [1] and remove board.


Information: Make sure not to disconnect the jumpers.

Figure 49: Remove signal and control board



2. Set push-to-run operation or self-retaining via red jumper on wiring board.
 - Link via B1 = self-retaining REMOTE
 - Link via B2 = push-to-run operation REMOTE (continuous signal REMOTE)

Figure 50: Wiring board




3. Fasten signal and control board [2] again.

10.4 Local controls: mount

1. Clean sealing faces of housing and cover.
2. Preserve joint surfaces with an acid-free corrosion protection agent.
3. Check whether O-ring [3] is in good condition, replace if damaged.
4. Apply a thin film of non-acidic grease (e.g. petroleum jelly) to the O-ring and insert it correctly.

Figure 51:



5. Fit local controls [1].

NOTICE

Cable damage due to twisting or pinching!

Risk of functional failures.

→ Carefully mount local controls.

6. Fasten screws evenly crosswise.

10.5 Controls: open

WARNING

Flameproof enclosure, danger of explosion!

Risk of death or serious injury.

→ Before opening, ensure that there is no explosive gas and no voltage.

→ Handle cover and housing parts with care.

→ Joint surfaces must not be damaged or soiled in any way.

→ Do not jam cover during fitting.


NOTICE

Electrostatic discharge ESD!

Risk of damage to electronic components.

→ Earth both operators and devices.

→ Loosen screws [2] and remove cover [1].




10.6 Feedback signals setting via output contacts

— (Option) —

Only valid for versions (B02 and B04) with relays K6, K7, K8 on relay board.

Figure 53: Relay board; left: version B02, right: version B04



→ Assign the required functions to the terminals XK ... of the customer connection (see wiring diagram) with the red jumpers.

Function (Signal at terminal XK ¹⁾ active, if function is correct)	Signal at terminal	Link
Torque switch tripped in mid-travel and/or Thermoswitch or thermal overload relay tripped	XK 16	
No torque switch tripped in mid-travel	XK 15	
No thermoswitch or no thermal overload relay tripped	XK 13	
Torque switch tripped in mid-travel	XK 16	
No torque switch tripped in mid-travel	XK 15	
No function	XK 13	
Torque switch tripped in mid-travel	XK 16	
No torque switch tripped in mid-travel	XK 15	
No thermoswitch or no thermal overload relay tripped	XK 13	
Torque switch tripped in mid-travel	XK 16	
No torque switch tripped in mid-travel	XK 15	
Thermoswitch or thermal overload relay tripped	XK 13	
Torque switch tripped in mid-travel	XK 16	
No torque switch tripped in mid-travel	XK 15	
No function	XK 13	
Common connection	XK 14	

1) Refer to order-related wiring diagram BSP ...

10.7 Controls: close


NOTICE

Danger of corrosion due to damage to paint finish!

→ Touch up damage to paint finish after work on the device.

1. Clean sealing faces of housing and cover.
2. Preserve joint surfaces with an acid-free corrosion protection agent.
3. Check whether O-ring [3] is in good condition, replace if damaged.

4. Apply a thin film of non-acidic grease (e.g. petroleum jelly) to the O-ring and insert it correctly.



Flameproof enclosure, danger of explosion!

Risk of death or serious injury.

- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

5. Place cover [1] on switch compartment.
6. Fasten screws [2] evenly crosswise.

11. Corrective action

11.1 Faults during commissioning

Table 8: Faults during commissioning

Fault description	Possible causes	Remedy
Mechanical position indicator cannot be set.	Reduction gearing is not suitable for turns/stroke of the actuator.	Exchange reduction gearing.
Fault in end position Actuator runs to end stop although the limit switches work properly.	The overrun was not considered when setting the limit switching. The overrun is generated by the inertia of both the actuator and the valve and the delay time of the controls.	Determine overrun: Overrun = travel covered from switching off until complete standstill. Set limit switching again considering the overrun (turn handwheel back by the amount of the overrun).
Position transmitter RWG Measurement range 4 – 20 mA or maximum value 20 mA cannot be set.	Reduction gearing is not suitable for turns/stroke of the actuator.	Exchange reduction gearing.
Limit and/or torque switches do not trip.	Switch is defective or switch setting is incorrect.	Check setting, if required, reset end positions. → Check switches and replace them, if required.

Switch check

The red test buttons [1] and [2] are used for manual operation of the switches:



1. Turn test button [1] in direction of the TSC arrow: Torque switch CLOSED trips. The red indication light (fault) on the local controls is illuminated.
2. Turn test button [2] in direction of the TSO arrow: Torque switch OPEN trips. The red indication light (fault) on the local controls is illuminated.

If the actuator is equipped with a DUO limit switching (option), the intermediate position switches (LSA and LSB) will be operated at the same time as the torque switches.

1. Turn test button [1] in direction of the LSC arrow: Limit switch CLOSED trips.
2. Turn test button [2] in direction of the LSO arrow: Limit switch OPEN trips.

11.2 Fuses

11.2.1 Fuses within the actuator controls

After removal of local controls, the fuses can be accessed.




Flameproof enclosure, danger of explosion!

Risk of death or serious injury.

- Before opening, ensure that there is no explosive gas and no voltage.
- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

Figure 56: Access to fuses



- [1] Local controls
- [2] Signal and control board
- [3] Power supply unit

F1/F2 Primary fuses on power supply unit

G fuse	F1/F2	AUMA art. no.
Size	6.3 x 32 mm	
Reversing contactors Power supply ≤ 500 V	1 A T; 500 V	K002.277
Reversing contactors Power supply > 500 V	2 A FF; 690 V	K002.665

F3 Internal 24 V DC supply

G fuse according to IEC 60127-2/III	F3	AUMA art. no.
Size	5 x 20 mm	
Voltage output (power supply unit) = 24 V	500 mA T; 250 V	K001.183
Voltage output (power supply unit) = 115 V	500 mA T; 250 V	K001.183

F4 Internal 24 V AC supply (115 V AC) for:

- Heater, switch compartment, reversing contactors control
- for 115 V AC also control inputs OPEN - STOP - CLOSE

G fuse according to IEC 60127-2/III	F4	AUMA art. no.
Size	5 x 20 mm	
Voltage output (power supply unit) = 24 V	1.0 A T; 250 V 1.6 A T; 250 V	K004.831 K003.131
Voltage output (power supply unit) = 115 V	0.4 A T; 250 V	K003.021

F5 Automatic reset fuse as short-circuit protection for external 24 V DC supply for customer (see wiring diagram)

Information Only use fuses of same type and value for replacement.

→ After replacing the fuses, fasten local controls again.

NOTICE

Cable damage due to twisting or pinching!

Risk of functional failures.

- Turn local controls by a maximum of 180°.
- Carefully assemble local controls to avoid pinching the cables.

11.2.2 Motor protection (thermal monitoring)

In order to protect against overheating and impermissibly high surface temperatures at the actuator, thermostats are embedded in the motor winding. The thermostat is tripped as soon as the max. permissible winding temperature has been reached.

The actuator is stopped and the red indication light (option) on the local controls is illuminated.

The motor has to cool down before operation can be resumed.

The operation may only be resumed once the fault signal (red indication light) has been reset. The fault signal is reset via the overload relay integrated in the actuator controls. Therefore the controls have to be opened at the cover and the relay held down. The relay is located on the contactors.

12. Servicing and maintenance



Damage caused by inappropriate maintenance!

- Servicing and maintenance must be carried out exclusively by suitably qualified personnel having been authorised by the end user or the contractor of the plant. Therefore, we recommend contacting our service.
- Only perform servicing and maintenance tasks when the device is switched off.

AUMA Service & Support

AUMA offer extensive service such as servicing and maintenance as well as customer product training. For the relevant contact addresses, please refer to <Addresses> in this document or to the Internet (www.auma.com).


12.1 Preventive measures for servicing and safe operation

The following measures are required to ensure safe device operation:

6 months after commissioning and then every year

- Carry out visual inspection:
Cable entries, cable glands, blanking plugs, etc. have to be checked for correct tightness and sealing.
Respect torques according to manufacturer's details.
- Check fastening screws between actuator and gearbox/valve for tightness. If required, fasten screws while applying the tightening torques as indicated in chapter <Assembly>.
- When rarely operated: Perform test run.
- For devices with output drive A: Press in Lithium soap EP multi-purpose grease on mineral oil base at the grease nipple with a grease gun.
- Lubrication of the valve stem must be done separately.

Figure 57: Output drive type A



- [1] Output drive type A
- [2] Grease nipple

Table 9: Grease quantities for bearing of output drive type A

Output drive	A 07.2	A 10.2	A 14.2	A 16.2
Quantity [g] ¹⁾	1.5	2	3	5

1) For grease at density $\rho = 0.9 \text{ kg/dm}^3$

For enclosure protection IP 68

After continuous immersion:

- Check actuator.
- In case of ingress of water, locate leaks and repair, dry device correctly and check for proper function.


12.2 Disconnection from the mains

If the device must be dismantled, e.g. for service purposes, it can be separated from the mains without having to remove the wiring.

**Flameproof enclosure, danger of explosion!***Risk of death or serious injury.*

- Before opening, ensure that there is no explosive gas and no voltage.
- Handle cover and housing parts with care.
- Joint surfaces must not be damaged or soiled in any way.
- Do not jam cover during fitting.

Figure 58: top: KP/KPH, bottom: KES



- [1] Cover
- [2] Screws for housing
- [3] O-ring
- [4] Terminal compartment
- [5] Terminal board (KP, KPH)
- [6] Frame (KES)

- Removing the plug:**
1. Loosen the screws [2].
 2. Remove plug/socket connector.
 - ➡ Hereby, cover [1] and terminal board [5] or frame [6] remain together.
 3. Seal open plug/socket connection, e.g. using AUMA protection cover and parking frame.
- Fitting the plug:**
4. Clean sealing faces at the cover and the housing.
 5. Preserve joint surfaces with an acid-free corrosion protection agent.
 6. Check whether O-ring [3] is in good condition, replace if damaged.
 7. Apply a thin film of non-acidic grease (e.g. petroleum jelly) to the O-ring and insert it correctly.
 8. Replace plug/socket connector and fasten screws evenly crosswise.

12.3 Maintenance

Maintenance intervals After 3 years at the latest for Ex certified products.

- Lubrication**
- In the factory, the gear housing is filled with grease.
 - Grease change is performed during maintenance
 - Generally after 4 to 6 years for modulating duty.
 - Generally after 6 to 8 years if operated frequently (open-close duty).
 - Generally after 10 to 12 years if operated rarely (open-close duty).

Notes regarding the maintenance

- We recommend exchanging the seals when changing the grease.
- No additional lubrication of the gear housing is required during operation.
- Check actuator visually. Ensure that no outside damage or changes are visible.
- The electric connection cables must be without damage and wired correctly.
- Do a thorough touch-up of possible damage to paint finish to prevent corrosion. Original paint in small quantities can be supplied by AUMA.
- Cable entries, cable glands, plugs etc. have to be checked for correct tightness and sealing. Consider torques according to manufacturer's details. If required, replace the components. Only use components which have an EC type examination certificate.
- Check whether Ex connections are fastened correctly.
- Take care of possible discolouration of the terminals and wires. This would indicate an increased temperature.
- For Ex housings, pay special attention to a possible collection of water. This may originate from "breathing" due to severe temperature variations (e. g. change of night and day), from damaged seals etc. Remove any water immediately.
- Check the flame path gaps of flameproof enclosures for dirt and corrosion.
- Since the dimensions of all flameproof joints are strictly defined and inspected, no mechanical work (such as grinding) shall be performed on them. The joint surfaces have to be cleaned chemically (e. g. with Esso-Varsol).
- Prior to fitting, preserve joint surfaces with an acid-free corrosion protection agent (e. g. Esso Rust-BAN 397).
- Ensure that all housing covers are handled carefully and that the seals are checked.
- All cable and motor protection components have to be checked.
- If defects impairing the safety are detected during maintenance, repair measures have to be initiated without delay.
- Any kind of surface coating for the joint surfaces is not permitted.
- When exchanging parts, seals etc. only original spare parts shall be used.

12.4 Disposal and recycling

Our devices have a long lifetime. However, they have to be replaced at one point in time. The devices have a modular design and may, therefore, easily be separated and sorted according to materials used, i.e.:

- electronic scrap
- various metals
- plastics
- greases and oils

The following generally applies:

- Greases and oils are hazardous to water and must not be released into the environment.
- Arrange for controlled waste disposal of the disassembled material or for separate recycling according to materials.
- Observe the national regulations for waste disposal.

13. Technical data

Information The following technical data includes standard and optional features. For detailed information on the customer-specific version, refer to the order-relevant data sheet. This data sheet can be downloaded from the Internet at <http://www.auma.com> in German and English (indication of commission number required).

13.1 Features and functions of actuator

Explosion protection	<p>Standard version (ATEX):</p> <ul style="list-style-type: none"> • II2G Ex de IIC (IIB, IIB+H₂) T4 (T3) Gb • II2D Ex tb IIIC T130°C (T190°C) Db IP68 • II2G c IIC T4 <p>Standard version (IECEx):</p> <ul style="list-style-type: none"> • Ex de IIC (IIB, IIB+H₂) T4 (T3) Gb • Ex tb IIIC T130°C (190°C) Db IP68 <p>For actual version, refer to actuator name plate.</p>
EC type examination certificate	<p>DEKRA 11ATEX0008 X DEKRA 12ATEX0143 X IECEx DEK 12.0022 X</p>
Protection type	<ul style="list-style-type: none"> • Ex d flameproof enclosure: <ul style="list-style-type: none"> - Motor compartment - Switch compartment - Controls housing - Terminal compartment (for electrical connection: KES-Exd) • Ex e increased safety: <ul style="list-style-type: none"> - Terminal compartment (for electrical connection: KP, KPH or KES) • Ex i Intrinsic safety: <ul style="list-style-type: none"> - Current circuit via electronic position transmitter RWG 5020.2 Ex (option) • c constructional safety: <ul style="list-style-type: none"> - Gear housing
Type of duty ¹⁾	<p>Standard:</p> <ul style="list-style-type: none"> • SAEx: Short-time duty S2 - 15 min • SAREx: Intermittent duty S4 - 25 % <p>Options:</p> <ul style="list-style-type: none"> • SAEx: Short-time duty S2 - 30 min • SAREx: Intermittent duty S4 - 50 %
Torque range	Refer to actuator name plate
Output speed	Refer to actuator name plate
Motor	Standard: 3-ph AC asynchronous motor, type IM B9 according to IEC 60034
Motor voltage and frequency	Refer to motor name plate
Insulation class	<p>Standard: F, tropicalized</p> <p>Option: H, tropicalized</p>
Motor protection	Thermoswitches (NC) in the actuator and in the thermal overload relay of the controls
Self-locking	<p>Self-locking: Output speeds up to 90 rpm (50 Hz), 108 rpm (60 Hz)</p> <p>NOT self-locking: Output speeds up to 125 rpm (50 Hz), 150 rpm (60 Hz)</p> <p>Multi-turn actuators are self-locking, if the valve position cannot be changed from standstill while torque acts upon the output drive.</p>
Limit switching	<p>Counter gear mechanism for end positions CLOSED and OPEN</p> <p>Turns per stroke: 2 to 500 (standard) or 2 to 5,000 (option)</p> <p>Standard:</p> <ul style="list-style-type: none"> • Single switches (1 NC and 1 NO, not galvanically isolated) for each end position <p>Options:</p> <ul style="list-style-type: none"> • Tandem switches (2 NC and 2 NO) for each end position, switches galvanically isolated • Triple switches (3 NC and 3 NO) for each end position, switches galvanically isolated • Intermediate position switch (DUO limit switching), adjustable for any position

Torque switching	Torque switching adjustable for directions OPEN and CLOSE Standard: Single switch (1 NC and 1 NO; not galvanically isolated) for each direction Option: Tandem switches (2 NC and 2 NO) for each direction, switches galvanically isolated
Position feedback signal, analogue (option)	Potentiometer or 0/4 – 20 mA (RWG)
Mechanical position indicator (option)	Continuous indication, adjustable indicator disc with symbols OPEN and CLOSED
Running indication	Blinker transmitter (standard for SA, option for SAR)
Heater in switch compartment	Standard: Resistance type heater, 5 W, 24 V DC, (internal supply)
Motor heater (option)	Voltages: 110 – 120 V AC, 220 – 240 V AC or 400 V AC (externally supplied) Power depending on the size 12.5 – 25 W
Manual operation	Manual drive for setting and emergency operation, handwheel does not rotate during electrical operation. Option: Handwheel lockable
Connection to controls	AUMA plug/socket connector with screw-type connection
Valve attachment	Standard: B1 according to EN ISO 5210 Options: A, B2, B3, B4 according to EN ISO 5210 A, B, D, E according to DIN 3210 C according to DIN 3338 Special output drive types: AF, B3D, ED, DD, IB1, IB3 A prepared for stem lubrication
Sensor system	
Indication for manual operation (option)	Indication whether manual operation is active/not active via switch (1 change-over contact)

- 1) For nominal voltage and 40 °C ambient temperature and an average load with running torque or modulating torque according to separate technical data. The type of duty must not be exceeded.

Technical data for limit and torque switches

Mechanical lifetime	2 x 10 ⁶ starts
Silver plated contacts:	
U min.	30 V AC/DC
U max.	250 V AC/DC
I min.	20 mA
I max. AC current	5 A at 250 V (resistive load) 3 A at 250 V (inductive load, cos phi = 0.6)
I max. DC current	0.4 A at 250 V (resistive load) 0.03 A at 250 V (inductive load, L/R = 3 µs) 7 A at 30 V (resistive load) 5 A at 30 V (inductive load, L/R = 3 µs)
Gold plated contacts:	
U min.	5 V
U max.	30 V
I min.	4 mA
I max.	400 mA

Technical data for blinker transmitter

Mechanical lifetime	10 ⁷ starts
Silver plated contacts:	
U min.	10 V AC/DC
U max.	250 V AC/DC
I max. AC current	3 A at 250 V (resistive load) 2 A at 250 V (inductive load, cos phi ≈ 0.8)
I max. DC current	0.25 A at 250 V (resistive load)

Technical data for handwheel activation switches	
Mechanical lifetime	10 ⁶ starts
Silver plated contacts:	
U min.	12 V DC
U max.	250 V AC
I max. AC current	3 A at 250 V (inductive load, cos phi = 0.8)
I max. DC current	3 A at 12 V (resistive load)

13.2 Features and functions of actuator controls

Power supply, mains frequency	For mains voltage and mains frequency, refer to name plates at the controls and the motor Permissible variation of the mains voltage: $\pm 10\%$ Permissible variation of the mains frequency: $\pm 5\%$ Option: Permissible variation of the mains voltage: -10%
Current consumption	Motor current consumption: Refer to motor name plate Current consumption of the controls depending on mains voltage: 100 to 120 V AC = max. 575 mA 208 to 240 V AC = max. 275 mA 380 to 500 V AC = max. 160 mA
Rated power	The controls are designed for the rated motor power, refer to motor name plate
Overvoltage category	Category III according to IEC 60364-4-443
Switchgear ^{1) 2)}	Standard: Reversing contactors (mechanically and electrically interlocked) for motor power up to power class A1 Options: <ul style="list-style-type: none"> Reversing contactors (mechanically and electrically interlocked) for motor power up to power class A2
Auxiliary voltage output	Standard: 230 V AC $\pm 10\%$, max. 2.5 W for supply of the control inputs., galvanically isolated from internal voltage supply Option: 24 V DC $\pm 5\%$, max. 10 mA for supply of the control inputs, galvanically isolated from internal voltage supply 115 V AC $\pm 10\%$, max. 30 mA for supply of the control inputs, galvanically isolated from internal voltage supply
Control	Standard: Control inputs OPEN - STOP - CLOSE, 230 V AC, internally supplied (non potential-free) EMERGENCY-STOP function from control room, independent of position of selector switch Options: Control inputs , OPEN - STOP - CLOSE, 24 V DC, externally supplied (with galvanic isolation via contact), current consumption: approx. 15 mA per input Control inputs OPEN - STOP - CLOSE, 24 V DC, internally supplied (non potential-free) Control inputs OPEN - STOP - CLOSE, 115 V AC, internally supplied (non potential-free)
Status signals	Standard: Output signals for end positions OPEN/CLOSED, 230 V AC, internally supplied (non potential-free) for external indication lights OPEN/CLOSE ($P_{\max} = 2.5\text{ W}$) Options: <ul style="list-style-type: none"> 5 potential-free output signals with one common, max. 250 V AC, 2 A (resistive load) <ul style="list-style-type: none"> Motor protection tripped (thermal fault) Torque fault No torque fault Selector switch position LOCAL/REMOTE
Position feedback signal (option)	Galvanically isolated analogue output E2 = 0/4 – 20 mA (load max. 300 Ω)

Local controls	<p>Standard:</p> <ul style="list-style-type: none"> • Selector switch LOCAL - OFF - REMOTE (lockable in all three positions) • Push buttons OPEN, STOP, CLOSE • 2 indication lights: <ul style="list-style-type: none"> - End position CLOSED (yellow), end position OPEN (green) <p>Options:</p> <ul style="list-style-type: none"> • 3 indication lights <ul style="list-style-type: none"> - End position CLOSED (yellow), fault (red), end position OPEN (green) • Special colours for the indication lights • Protection cover, lockable
Functions	<p>Standard:</p> <ul style="list-style-type: none"> • Switch-off mode adjustable <ul style="list-style-type: none"> - Limit or torque seating for end position OPEN and end position CLOSED • Overload protection against excessive torques over the whole travel • Phase failure monitoring with automatic phase correction • Push-to-run operation or self-retaining in REMOTE • Push-to-run operation or self-retaining in LOCAL
Motor protection evaluation	<p>Standard:</p> <p>Thermal overload relay in combination with thermoswitches in the actuator motor</p>
Electrical connection	<p>Standard:</p> <p>Plug/socket connector with screw-type terminals (KP, KPH) Ex e (increased safety) and M-threads</p> <p>Options:</p> <ul style="list-style-type: none"> • Plug/socket connector with terminal blocks (KES) Ex e (increased safety) • Plug/socket connector with terminal blocks (KES) Ex d (flameproof enclosure) • Pg-threads, NPT-threads, G-threads, special threads • Parking frame for wall mounting of the disconnected plug • Protection cover for plug compartment (when plug is removed)
Wiring diagram	Refer to name plate

- 1) The reversing contactors are designed for a lifetime of 2 million starts.
- 2) For the assignment of AUMA power classes, please refer to electrical data on actuator.

13.3 Service conditions

Use	Indoor and outdoor use permissible
Mounting position	Any position
Enclosure protection according to EN 60529	<p>Standard: IP 68 with AUMA 3-ph AC motor/1-ph AC motor According to AUMA definition, enclosure protection IP 68 meets the following requirements:</p> <ul style="list-style-type: none"> • Depth of water: maximum 8 m head of water • Duration of continuous immersion in water: max. 96 hours • Up to 10 operations during flooding. • Modulating duty is not possible during continuous immersion. <p>For enclosure protection IP 68, the terminal compartment is additionally sealed against the interior – double sealed. For actual version, refer to actuator/controls name plate.</p>
Corrosion protection	<p>Standard:</p> <ul style="list-style-type: none"> • KS: Suitable for installation in industrial units, in water or power plants with a low pollutant concentration as well as for installation in occasionally or permanently aggressive atmosphere with a moderate pollutant concentration (e.g. in wastewater treatment plants, chemical industry) <p>Options:</p> <ul style="list-style-type: none"> • KX: Suitable for installation in extremely aggressive atmospheres with high humidity and high pollutant concentration
Installation altitude	<p>Standard: ≤ 2,000 m above sea level Option: > 2,000 m above sea level, please contact AUMA</p>
Pollution degree	Pollution degree 4 (when closed) according to 50178

Technical data

Finish coating	Standard: Paint based on polyurethane (powder coating)
Colour	Standard: AUMA silver-grey (similar to RAL 7037)
Ambient temperature	Standard: <ul style="list-style-type: none"> –20 °C to +40/+60 °C For actual version, refer to actuator/controls name plate.
Vibration resistance according to IEC 60068-2-6	1 g, from 10 to 200 Hz Resistant to vibration during start-up or for failures of the plant. However, a fatigue strength may not be derived from this. Not valid in combination with gearboxes.
Lifetime	AUMA multi-turn actuators meet or exceed the lifetime requirements of EN 15714-2. For further details, please contact AUMA
Weight	Refer to separate technical data

13.4 Further information

EU Directives	<ul style="list-style-type: none"> • ATEX Directive: (94/9/EC) • Electromagnetic Compatibility (EMC): (2004/108/EC) • Low Voltage Directive: (2006/95/EC) • Machinery Directive: (2006/42/EC)
---------------	---

14.1	Multi-turn actuators SAEx 07.2 – SAEx 16.2/SAREx 07.2 – SAREx 16.2 with plug/socket connector and screw-type terminals (KP, KPH)
------	--




Spare parts

Information: Please state type and commission no. of the device (see name plate) when ordering spare parts. Only original AUMA spare parts should be used. Failure to use original spare parts voids the warranty and exempts AUMA from any liability. Delivered spare parts may slightly vary from the representation in these instructions.

No.	Designation	Type	No.	Designation	Type
002.0	Bearing flange	Sub-assembly	535.1	Snap ring	
003.0	Hollow shaft with worm wheel	Sub-assembly	539.0	Screw plug	Sub-assembly
005.0	Drive shaft	Sub-assembly	542.0	Handwheel with ball handle	Sub-assembly
005.1	Motor coupling on output drive shaft		549.0	Output drive type B1/B3/B4/E	Sub-assembly
005.3	Manual drive coupling		549.1	Output drive sleeve B1/B3/B4/C	
009.0	Planetary gearing for manual drive	Sub-assembly	553.0	Mechanical position indicator	Sub-assembly
017.0	Torque lever	Sub-assembly	554.0	Socket carrier with motor cable harness	Sub-assembly
018.0	Gear segment		556.0	Potentiometer for position transmitter	Sub-assembly
019.0	Crown wheel	Sub-assembly	556.1	Potentiometer without slip clutch	
022.0	Drive pinion II for torque switching	Sub-assembly	557.0	Heater	Sub-assembly
023.0	Output drive wheel for limit switching	Sub-assembly	558.0	Blinker transmitter including pins at wires (without impulse disc and insulation plate)	Sub-assembly
024.0	Drive wheel for limit switching	Sub-assembly	559.0-1	Control unit without torque switching heads, without switches	Sub-assembly
025.0	Locking plate	Sub-assembly	559.0-2	Control unit with magnetic limit and torque transmitter (MWG) for Non-intrusive version in combination with AUMATIC integral controls	Sub-assembly
058.0	Wire for protective earth (pin)	Sub-assembly	560.0-1	Switch stack for direction OPEN	Sub-assembly
070.0	Motor (VD motor incl. no. 079.0)	Sub-assembly	560.0-2	Switch stack for direction CLOSE	Sub-assembly
079.0	Planetary gear for motor drive (SA/SAR 07.2 – 16.2 for VD motor)	Sub-assembly	560.1	Switch for limit/torque	
155.0	Reduction gearing	Sub-assembly	560.2	Switch case	
500.0	Cover for switch compartment	Sub-assembly	566.0	Position transmitter RWG	Sub-assembly
501.0	Terminal board	Sub-assembly	566.1	Potentiometer for RWG without slip clutch	Sub-assembly
501.1	Screw – Control terminal		566.2	Electronic board RWG	Sub-assembly
501.2	Washer – Control terminal		566.3	Wires for RWG	Sub-assembly
501.3	Screw – Power terminal		567.1	Slip clutch for potentiometer/RWG	Sub-assembly
501.4	Washer – Power terminal		568.1	Stem protection tube (without cap)	
502.1	Pin carrier (without pins)	Sub-assembly	568.2	Cap for stem protection tube	
505.0	Pin for controls	Sub-assembly	568.3	V-Seal	
506.0	Pin for motor	Sub-assembly	574.1	Radial seal output drive type A for ISO flange	
507.0	Plug cover	Sub-assembly	575.1	Stem nut type A	
511.0	Threaded plug		583.0	Motor coupling on motor shaft	Sub-assembly
514.0	Output drive type A (without stem nut)	Sub-assembly	583.1	Pin for motor coupling	
514.1	Axial needle roller bearing		584.0	Retaining spring for motor coupling	Sub-assembly
516.0	Output drive type D		S1	Seal kit, small	Set
			S2	Seal kit, large	Set


14.2 **Actuator controls AUMA MATIC BASIC AMBExC 01.1 with plug/socket connector with screw-type connection (KP, KPH)**



Information: Please state type and commission no. of the device (see name plate) when ordering spare parts. Only original AUMA spare parts should be used. Failure to use original spare parts voids the warranty and exempts AUMA from any liability. Delivered spare parts may slightly vary from the representation in these instructions.

No.	Designation	Type
001.0	Housing	Sub-assembly
002.0	Local controls	Sub-assembly
002.5	Selector switch	Sub-assembly
003.0	Signal and control board	Sub-assembly
003.1	Primärsicherung F1/F2	Sub-assembly
003.2	Cover for fuse	Sub-assembly
004.0	Carrier for contactors	Sub-assembly
006.0	Power supply unit including mounting plate	Sub-assembly
006.1	Secondary fuse F3	
006.2	Secondary fuse F4	
006.3	Secondary fuse F5	
008.0	Relay board	Sub-assembly
013.0	Wiring board	Sub-assembly
500.0	Cover	Sub-assembly
501.0	Terminal board	Sub-assembly
501.1	Screw for control terminal	
501.2	Washer for control terminal	
501.3	Screw for power terminal	
501.4	Washer for power terminal	
502.0	Pin carrier without pins	Sub-assembly
505.0	Pin for controls	Sub-assembly
506.0	Pin for motor	Sub-assembly
507.0	Plug cover	Sub-assembly
508.0	Switchgear	Sub-assembly
509.1	Padlock	
532.0	Line bushing (actuator connection)	Sub-assembly
535.1	Circlip	
S	Seal kit	Set

14.3 Actuator controls AUMA MATIC BASIC AMBExC 01.1 with plug/socket connector and terminal blocks (KES)



Spare parts

Information: Please state type and commission no. of the device (see name plate) when ordering spare parts. Only original AUMA spare parts should be used. Failure to use original spare parts voids the warranty and exempts AUMA from any liability. Delivered spare parts may slightly vary from the representation in these instructions.

No.	Designation	Type
001.0	Housing	Sub-assembly
002.0	Local controls	Sub-assembly
002.5	Selector switch	Sub-assembly
003.0	Signal and control board	Sub-assembly
003.1	Primary fuse F1/F2	Sub-assembly
003.2	Cover for fuse	Sub-assembly
004.0	Carrier for contactors	Sub-assembly
006.0	Power supply unit including mounting plate	Sub-assembly
006.1	Secondary fuse F3	
006.2	Secondary fuse F4	
006.3	Secondary fuse F5	
008.0	Relay board	Sub-assembly
013.0	Wiring board	Sub-assembly
500.0	Cover	Sub-assembly
502.0	Pin carrier without pins	Sub-assembly
505.0	Pin for controls	Sub-assembly
506.0	Pin for motor	Sub-assembly
507.0	Plug cover	Sub-assembly
508.0	Switchgear	Sub-assembly
509.1	Padlock	
528.0	Terminal frame (without terminals)	Sub-assembly
529.0	End piece	
532.0	Line bushing (actuator connection)	Sub-assembly
533.0	Terminals for motor/controls	
535.1	Circlip	
573.0	Plug-in electrical connection	Sub-assembly
S	Seal kit	Set

15. Certificates

15.1 Declaration of Incorporation and EC Declaration of Conformity

AUMA Riester GmbH & Co. KG
Aumastr. 1
79379 Müllheim, Germany
www.auma.com

Tel +49 7631 809-0
Fax +49 7631 809-1250
Riester@auma.com



Original Declaration of Incorporation of Partly Completed Machinery (EC Directive 2006/42/EC) and EC Declaration of Conformity in compliance with the Directives on EMC, Low Voltage and Explosion Protection

for electric AUMA multi-turn actuators of the type ranges **SAEx 07.2 – SAEx 16.2** and
SAREx 07.2 – SAREx 16.2 in version **AUMA NORM, AUMA SEMIPACT, AUMA MATIC** or **AUMATIC**.

AUMA Riester GmbH & Co. KG as manufacturer declares herewith, that the above mentioned multi-turn actuators meet the following basic requirements of the EC Machinery Directive 2006/42/EC: Annex I, articles 1.1.2, 1.1.3, 1.1.5, 1.2.1; 1.2.6, 1.3.1, 1.3.7, 1.5.1, 1.6.3, 1.7.1, 1.7.3, 1.7.4

The following harmonised standards within the meaning of the Machinery Directive have been applied:

EN 12100-1: 2003	ISO 5210: 1996
EN 12100-2: 2003	EN 60204-1: 2006

With regard to the partly completed machinery, the manufacturer commits to submitting the documents to the competent national authority via electronic transmission upon request. The relevant technical documentation pertaining to the machinery described in Annex VII, part B has been prepared.

AUMA multi-turn actuators are designed to be installed on industrial valves. AUMA multi-turn actuators must not be put into service until the final machinery into which they are to be incorporated has been declared in conformity with the provisions of the EC Directive 2006/42/EC.

Authorised person for documentation: Peter Malus, Aumastrasse 1, D-79379 Müllheim

As partly completed machinery, the multi-turn actuators further comply with the requirements of the following directives and the respective approximation of national laws as well as the respective harmonised standards as listed below:

(1) Equipment and protective systems intended for use in potentially explosive atmospheres (94/9/EC)

EN 60079-0: 2006	EN 60079-11: 2007	EN 1127-1: 2007
EN 60079-1: 2007	EN 13463-1: 2009	
EN 60079-7: 2007	EN 13463-5: 2003	

The EC type examination certificate DEKRA 11 ATEX 008 X issued by the DEKRA Certification B.V. is available for the multi-turn actuators mentioned above.

(2) Directive relating to Electromagnetic Compatibility (EMC) (2004/108/EC)

EN 61000-6-4: 2007
EN 61000-6-2: 2005

(3) Low Voltage Directive (2006/95/EC)

EN 60204-1: 2006	EN 60034-1: 2004
EN 50178: 1997	EN 61010-1: 2001

Müllheim, 2011-09-01

H. Newerla, General Management

This declaration does not contain any guarantees. The safety instructions in product documentation supplied with the devices must be observed. Non-concerted modification of the devices voids this declaration.

Y005.176/002/en

15.2 ATEX certificate



CERTIFICATE

(1) EC-Type Examination

(2) Equipment and protective systems intended for use in potentially explosive atmospheres - Directive 94/9/EC

(3) EC-Type Examination Certificate Number: **DEKRA 11ATEX0008 X** Issue Number: 1

(4) Equipment: **Multi-Turn Actuator, Types SA.Ex 07.2 to SA.Ex 16.2 in version AUMA NORM, AUMA MATIC or AUMATIC**

(5) Manufacturer: **Auma Riester GmbH & Co. KG**

(6) Address: **Aumastrasse 1, 79379 Müllheim, Germany**

(7) This equipment and any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.

(8) DEKRA Certification B.V., notified body number 0344 in accordance with Article 9 of the Council Directive 94/9/EC of 23 March 1994, certifies that this equipment has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment and protective systems intended for use in potentially explosive atmospheres given in Annex II to the directive.

The examination and test results are recorded in confidential test report number NL/DEK/ExTR11.0044/xx.

(9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:

EN 60079-0 : 2009
EN 61241-0 : 2006

EN 60079-1 : 2007
EN 61241-1 : 2004

EN 60079-7 : 2007

(10) If the sign "X" is placed after the certificate number, it indicates that the equipment is subject to special conditions for safe use specified in the schedule to this certificate.

(11) This EC-Type Examination Certificate relates only to the design, examination and tests of the specified equipment according to the Directive 94/9/EC. Further requirements of the directive apply to the manufacturing process and supply of this equipment. These are not covered by this certificate.

(12) The marking of the equipment shall include the following:



II 2 G Ex d IIC T4 or T3 Gb or Ex d IIB T4 or T3 Gb
II 2 G Ex de IIC T4 or T3 Gb or Ex de IIB T4 or T3 Gb
II 2 D Ex tD A21 IP6x T130 °C or T190 °C

This certificate is issued on 29 July 2011 and, as far as applicable, shall be revised before the date of cessation of presumption of conformity of (one of) the standards mentioned above as communicated in the Official Journal of the European Union.

DEKRA Certification B.V.

C.G. van Es
Certification Manager

Page 1/4

* Integral publication of this certificate and adjoining reports is allowed. This Certificate may only be reproduced in its entirety and without any change.



All testing, inspection, auditing and certification activities of the former KEMA Quality are an integral part of the DEKRA Certification Group

DEKRA Certification B.V. Utrechtseweg 310, 6812 AR Arnhem P.O. Box 5185, 6802 ED Arnhem The Netherlands
T +31 26 3 56 20 00 F +31 26 3 52 58 00 www.dekra-certification.com Registered Arnhem 09085396

DEKRA		DEKRA	
(13) SCHEDULE	(14) to EC-Type Examination Certificate DEKRA 11ATEX0008 X	(13) SCHEDULE	(14) to EC-Type Examination Certificate DEKRA 11ATEX0008 X
Issue No. 1		Issue No. 1	
(15) Description		Electrical data	
The Multi-turn actuator, types SAEx 07.2 to SAEx 16.2 in version AUMA NORM, AUMA MATIC or AUMATIC are in type of protection flameproof enclosure "d" for the motor, the controls and the switch compartment. The terminal compartment is in type of protection increased safety "e" or flameproof enclosures "d", in order to guarantee the temperature class, the 3-ph and 1-ph AC motor is equipped either with thermo switches and a thermal overload relay or with PTC's (three for 3-ph and one for 1-ph AC motor) integrated in each winding and a suitable electronics device for switching off in case of over temperature.		3-phase AC motor	
Ambient temperature range -20 °C to +60 °C.		1-phase AC motor	
The multi-turn actuators are classified for the temperature class T4/T130 °C and may be classified for the temperature class T3/T190 °C if required, for instance for prolonged running times.		Actuator size	
Multi-turn actuators		Motor size	
The type designation of the multi-turn actuators is composed as follows:		Power ⁽¹⁾	
SAEx 10.2-F10		SAEx 07.2	
Multi-turn actuator SA		ADK / VDX 63	
Additional designation for the version without, = standard		SAEx 07.6	
R = modulating duty		ADK / VDX 63	
explosion-proof version		SAEx 10.2	
Size: 07.2; 07.6; 10.2; 14.2; 14.6; 16.2		ADK / VDX 71	
Designation for mounting flange		SAEx 14.2	
Example:		ADK / VDX 90	
SAREx 07.6 - F07 Multi-turn actuator for modulating duty in type of duty S4...% or S5...%		SAEx 14.6	
Integral controls		ADK / VDX 90	
AMExC 01.1		SAEx 16.2	
Type of controls		ADK 112 / VDX 112	
AC = AUMATIC			
AM = AUMA MATIC			
AMMC = AUMA MATIC MC			
SEM = Semipact			
AMB = AUMA MATIC Basic			
Explosion-proof version for group IIC			
Size 01.1			
Size 01.2 (only Type ACEX01.2)			
Example:			
AMBExC 01.1 Integral controls type AUMA MATIC Basic (reversing contactors)			
Page 2/4		Page 3/4	
Form 100		Form 100	
Version 2 (2011-05)		Version 2 (2011-05)	

DEKRA	
(13) SCHEDULE	(14) to EC-Type Examination Certificate DEKRA 11ATEX0008 X
Issue No. 1	
Motor type: 1-phase AC Asynchronous motor	
Motor voltage: 240 V max.	
Motor current: 25 A max.	
Control voltage: 250 V max.	
Control current: 5 A max.	
Frequency: 50/60 Hz	
Isolation class: F or H	
Circuit type: single phase	
Operation type: S2 - ... min	
S4 - ... % ED	
S5 - ... % ED	
Installation instructions	
The instructions provided with the equipment shall be followed in detail to assure safe operation.	
(16) Test Report	No. NL/DEK/EXTR11.0044xx.
(17) Special conditions for safe use	The flame path length is other than required by EN 60079-1. Contact the manufacturer for information on the dimensions of the flameproof joints.
The apparatus shall not be used in applications where there is a high risk of mechanical danger.	
The multi-turn actuators are provided with special fasteners of property class A2-70.	
(18) Essential Health and Safety Requirements	Covered by the standards listed at (9).
(19) Test documentation	As listed in Test Report No. NL/DEK/EXTR11.0044xx.
Page 4/4	
Form 100	
Version 2 (2011-05)	

Index**A**

ATEX certificate	62
Accessories (electrical connection)	23
Accessories for assembly	15
Actuator operation from remote	26
Ambient temperature	54
Analogue signals	28
Applications	6
Approval mark	9
Assembly	11

B

Blinker transmitter	28
---------------------	----

C

Commission number	9
Commissioning	5
Commissioning – controls	38
Control	9
Corrective action	44
Corrosion protection	10 , 53
Current consumption	17

D

DUO limit switching	32
Declaration of Incorporation	61
Direction of rotation	33
Directives	5
Disposal	49

E

EC Declaration of Conformity	61
EC type examination certificate	9
Earth connection	24
Electrical connection	17
Electronic position transmitter	35
Enclosure protection	53
Explosion protection	9

F

Fault signal	27
Feedback signals (binary)	28
Feedback signals setting	41

H

Handwheel	11
-----------	----

I

Identification	8
Indication lights	27
Indications	27
Indicator disc	27 , 36
Inspection record	9
Intermediate positions	32

L

Limit seating	38
Limit switching	30 , 34
Local control	25
Local controls	25
Lubrication	48

M

Mains frequency	17
Mains voltage	17
Maintenance	5 , 47 , 48
Manual operation	25
Mechanical position indicator	27 , 36
Motor heater	20 , 22
Motor operation	25
Motor protection	28

N

Name plate	8 , 17
------------	--------

O

Operation	5 , 25
Output contacts setting	41
Output drive type A	12
Output drive types B, B1, B2, B3, B4, and E	11

P

Packaging	10
Parking frame	23
Position indicator	36
Position transmitter RWG	35
Potentiometer	34
Power supply	17 , 17
Protection cover	24
Protection on site	17
Protective measures	5
Push-to-run operation: set	39

Q

Qualification of staff	5
------------------------	---

R

RWG	35
Range of application	5
Recycling	49
Remote actuator operation	26
Running indication	27 , 28

S

Safety instructions	5
Safety instructions/warnings	5
Self-retaining: set	39
Service	47
Service conditions	53
Servicing	47
Short-circuit protection	17
Signals	28
Signals (analogue)	28
Spare parts	55
Standards	5
Stem nut	13
Stem protection tube	15
Storage	10
Support	47
Switch check	44

T

Technical data	50
Technical data for switches	51
Terminal cross sections	18 , 21
Terminal plan	17
Test run	33
Thermoswitches	28
Tightening torques	18 , 21
Torque fault	28
Torque seating	38
Torque switching	30
Transport	10
Type and size	9
Type of current	17
Type of seating: set	38

V

Valve position	28
Valve stem	15

W

Wiring diagram	9 , 17
----------------	--------

Europe

AUMA Riester GmbH & Co. KG

Plant Müllheim
DE 79373 Müllheim
 Tel +49 7631 809 - 0
 Fax +49 7631 809 - 1250
 riester@auma.com
 www.auma.com

Plant Ostfildern - Nellingen
DE 73747 Ostfildern
 Tel +49 711 34803 - 0
 Fax +49 711 34803 - 3034
 riester@wof.auma.com

Service-Center Köln
DE 50858 Köln
 Tel +49 2234 2037 - 900
 Fax +49 2234 2037 - 9099
 service@sck.auma.com

Service-Center Magdeburg
DE 39167 Niederndodeleben
 Tel +49 39204 759 - 0
 Fax +49 39204 759 - 9429
 Service@scm.auma.com

Service-Center Bayern
DE 85386 Eching
 Tel +49 81 65 9017- 0
 Fax +49 81 65 9017- 2018
 Riester@scb.auma.com

AUMA Armaturentriebe GmbH
AT 2512 Tribuswinkel
 Tel +43 2252 82540
 Fax +43 2252 8254050
 office@auma.at
 www.auma.at

AUMA (Schweiz) AG
CH 8965 Berikon
 Tel +41 566 400945
 Fax +41 566 400948
 RettichP.ch@auma.com

AUMA Servopohony spol. s.r.o.
CZ 250 01 Brandýs n.L.-St.Boleslav
 Tel +420 326 396 993
 Fax +420 326 303 251
 auma-s@auma.cz
 www.auma.cz

OY AUMATOR AB
FI 02230 Espoo
 Tel +358 9 5840 22
 Fax +358 9 5840 2300
 auma@aumator.fi
 www.aumator.fi

AUMA France S.A.R.L.
FR 95157 Taverny Cedex
 Tel +33 1 39327272
 Fax +33 1 39321755
 info@auma.fr
 www.auma.fr

AUMA ACTUATORS Ltd.
UK Clevedon, North Somerset BS21 6TH
 Tel +44 1275 871141
 Fax +44 1275 875492
 mail@auma.co.uk
 www.auma.co.uk

AUMA ITALIANA S.r.l. a socio unico
IT 20023 Cerro Maggiore (MI)
 Tel +39 0331 51351
 Fax +39 0331 517606
 info@auma.it
 www.auma.it

AUMA BENELUX B.V.
NL 2314 XT Leiden
 Tel +31 71 581 40 40
 Fax +31 71 581 40 49
 office@auma.nl
 www.auma.nl

AUMA Polska Sp. z o.o.
PL 41-219 Sosnowiec
 Tel +48 32 783 52 00
 Fax +48 32 783 52 08
 biuro@auma.com.pl
 www.auma.com.pl

OOO Priwody AUMA
RU 124365 Moscow a/ya 11
 Tel +7 495 221 64 28
 Fax +7 495 221 64 38
 aumarussia@auma.ru
 www.auma.ru

ERICHs ARMATUR AB
SE 20039 Malmö
 Tel +46 40 311550
 Fax +46 40 945515
 info@erichsarmatur.se
 www.erichsarmatur.se

GRØNBECH & SØNNER A/S
DK 2450 København SV
 Tel +45 33 26 63 00
 Fax +45 33 26 63 21
 GS@g-s.dk
 www.g-s.dk

IBEROPLAN S.A.
ES 28027 Madrid
 Tel +34 91 3717130
 Fax +34 91 7427126
 iberoplan@iberoplan.com

D. G. Bellos & Co. O.E.
GR 13671 Acharnai Athens
 Tel +30 210 2409485
 Fax +30 210 2409486
 info@dgbellos.gr

SIGURD SØRUM AS
NO 1300 Sandvika
 Tel +47 67572600
 Fax +47 67572610
 post@sigum.no

INDUSTRA
PT 2710-297 Sintra
 Tel +351 2 1910 95 00
 Fax +351 2 1910 95 99
 industria@talis-group.com

Auma Endüstri Kontrol Sistemleri Limited
 irketi
TR 06810 Ankara
 Tel +90 312 217 32 88
 Fax +90 312 217 33 88
 Servis@auma.com.tr
 www.megaendustri.com.tr

AUMA Technology utomations Ltd.
UA 02099 Kiyiv
 Tel +38 044 586-53-03
 Fax +38 044 586-53-03
 auma-tech@aumatech.com.ua

Africa

AUMA South Africa (Pty) Ltd.
ZA 1560 Springs
 Tel +27 11 3632880
 Fax +27 11 8185248
 aumasa@mweb.co.za

A.T.E.C.
EG Cairo
 Tel +20 2 23599680 - 23590861
 Fax +20 2 23586621
 atec@intouch.com

CMR Contrôle Maintenance Régulation
TN 1002 Tunis
 Tel +216 71 903 577
 Fax +216 71 903 575
 instrum@cmr.com.tn
 www.cmr-tunisie.net

MANZ INCORPORATED LTD.
NG Port Harcourt
 Tel +234-84-462741
 Fax +234-84-462741
 mail@manzincorporated.com
 www.manzincorporated.com

America

AUMA ACTUATORS INC.
US PA 15317 Canonsburg
 Tel +1 724-743-AUMA (2862)
 Fax +1 724-743-4711
 mailbox@auma-usa.com
 www.auma-usa.com

AUMA Argentina Representative Office
AR 1609 Boulogne
 Tel/Fax +54 232 246 2283
 contacto@aumaargentina.com.ar

AUMA Automação do Brasil Ltda.
BR São Paulo
 Tel +55 11 4612-3477
 contato@auma-br.com

AUMA Chile Representative Office
CL 9500414 Buin
 Tel +56 2 821 4108
 Fax +56 2 281 9252
 aumachile@adsl.tie.cl

TROY-ONTOR Inc.
CA L4N 8X1 Barrie Ontario
 Tel +1 705 721-8246
 Fax +1 705 721-5851
 troy-ontor@troy-ontor.ca

Ferrostaal de Colombia Ltda.
CO Bogotá D.C.
 Tel +57 1 401 1300
 Fax+57 1 416 5489
 dorian.hernandez@ferrostaal.com
 www.ferrostaal.com

PROCONTIC Procesos y Control
 Automático
EC Quito
 Tel +593 2 292 0431
 Fax +593 2 292 2343
 info@procontic.com.ec

Corsusa International S.A.C.
PE Miraflores - Lima
 Tel +511444-1200 / 0044 / 2321
 Fax +511444-3664
 corsusa@corsusa.com
 www.corsusa.com

PASSCO Inc.
PR 00936-4153 San Juan
 Tel +18 09 78 77 20 87 85
 Fax +18 09 78 77 31 72 77
 Passco@prtc.net

Suplibarca
VE Maracaibo Estado, Zulia
 Tel +58 261 7 555 667
 Fax +58 261 7 532 259
 suplibarca@intercable.net.ve

Asia

AUMA Actuators (Tianjin) Co., Ltd.
CN 300457 Tianjin
 Tel +86 22 6625 1310
 Fax +86 22 6625 1320
 mailbox@auma-china.com
 www.auma-china.com

AUMA INDIA PRIVATE LIMITED
IN 560 058 Bangalore
 Tel +91 80 2839 4656
 Fax +91 80 2839 2809
 info@auma.co.in
 www.auma.co.in

AUMA JAPAN Co., Ltd.
JP 211-0016 Nakaharaku, Kawasaki-shi Kanagawa
 Tel +81 44 863 8371
 Fax +81 44 863 8372
 mailbox@auma.co.jp
 www.auma.co.jp

AUMA ACTUATORS (Singapore) Pte Ltd.
SG 569551 Singapore
 Tel +65 6 4818750
 Fax +65 6 4818269
 sales@auma.com.sg
 www.auma.com.sg

AUMA Actuators Middle East W.L.L.
AE 15268 Salmabad 704
 Tel +973 17877377
 Fax +973 17877355
 Naveen.Shetty@auma.com

PERFECT CONTROLS Ltd.
HK Tsuen Wan, Kowloon
 Tel +852 2493 7726
 Fax +852 2416 3763
 joeip@perfectcontrols.com.hk

DW Controls Co., Ltd.
KR 153-702 Seoul
 Tel +82 2 2624 3400
 Fax +82 2 2624 3401
 sichoi@actuatorbank.com
 www.actuatorbank.com

Sunny Valves and Intertrade Corp. Ltd.
TH 10120 Yannawa Bangkok
 Tel +66 2 2400656
 Fax +66 2 2401095
 sunnyvalves@inet.co.th
 www.sunnyvalves.co.th/

Top Advance Enterprises Ltd.
TW Jhonghe City Taipei Hsien (235)
 Tel +886 2 2225 1718
 Fax +886 2 8228 1975
 support@auma-taiwan.com.tw
 www.auma-taiwan.com.tw

Australia

BARRON GJM Pty. Ltd.
AU NSW 1570 Artarmon
 Tel +61 294361088
 Fax +61 294393413
 info@barron.com.au
 www.barron.com.au

AUMA Riester GmbH & Co. KG
P.O.Box 1362
D 79373 Muellheim
Tel +49 7631 809 - 0
Fax +49 7631 809 - 1250
riester@auma.com
www.auma.com